

Large Hammock Stand



Congratulations on your purchase! We believe you will find this Large Hammock Stand to be a product of unsurpassed quality and durability.

Hardware included:

3 - Poles
2 - Foot Brackets*
2 - Offset S-Hooks
2 - Protective Pole Caps
(usually pre-fitted to poles)

4 - Protective Foot Caps*
(usually pre-fitted to poles)
2 - Hooks With Chain
(included with some models)

* Depending on the particular model of Large Hammock Stand, Foot Brackets and corresponding Foot Caps will be either round or square.





ASSEMBLY:

1. Arrange the two Foot Brackets flat on the ground opposite each other. (For stands with **square** foot brackets, make sure the shorter side of each Foot Bracket's elbow section is facing the other Foot Bracket; otherwise, Foot Brackets will not sit level on the ground.)
2. Place the Pole with no Protective Pole Caps between the two Foot Brackets (if Pole End Caps are not already pre-installed, then any of the three Poles will work here). Use the fitted steel spring pin in each Foot Bracket to connect the Foot Bracket to the Pole by depressing the spring pin and sliding the Pole over the pin; the pin should clear the lip of the Pole and pop out the hole, locking Pole and Foot Bracket together.
3. Using the spring pins, create the two stand arms by attaching the remaining two Poles to the unused section of each Foot Bracket elbow.
4. If Protective Pole Caps or Protective Foot Caps are not pre-installed, install them now.
5. Fit the **wide side** of one Offset S-Hook into the hole at the top of each stand arm.
6. Hang your hammock using the chains that come provided either with the hammock, or with some models of the Large Hammock Stand. Attach a link of chain to both Offset S-Hooks fitted earlier to stand arms. Ropes will stretch the first few uses; once stretched completely, readjust chain links to achieve your most comfortable hammock hanging height.

WARRANTY:

HammockSource products are guaranteed free of defects in workmanship and materials for up to two years from date of purchase. If an item is found to be defective within that time, The HammockSource will replace it at no charge. Normal wear and tear, including prolonged exposure to snow, rain and heavy humidity, is not covered, nor is mold, mildew or damage from improper storage, maintenance or installation. An original sales receipt must accompany any returned product, along with a Return Authorization Number from HammockSource customer service; call toll-free at (800) 643-3522.

Questions about our products? Call our toll-free customer-service line, **800.643.3522**, or visit www.thehammocksource.com.



CARE & MAINTENANCE OF STAND:

- Periodically inspect stand surface for clinging debris, wiping it off to prevent long-term damage to stand exterior.
- Do not leave stand sitting in pools of rainwater.

CAUTION! CAUTION! CAUTION!

STANDS WITH **ROUND** FOOT BRACKETS: **WEIGHT LIMIT 600 LBS.**

STANDS WITH **SQUARE** FOOT BRACKETS: **WEIGHT LIMIT 450 LBS.**

■ **USE CAUTION WHEN GETTING INTO HAMMOCK THE FIRST FEW TIMES**, until ropes are fully stretched from initial use.

■ **STANDS SHOULD BE EXAMINED PERIODICALLY TO ENSURE:**

- Each welded joint is intact, and there is no excessive rust.
- No Pole Caps or Foot Caps have come loose.

■ **HAMMOCKS SHOULD BE EXAMINED BEFORE EACH USE TO ENSURE:**

- All ropes are intact and not overly frayed.
- No chains have become twisted, which can compromise chain strength.

■ **DO NOT ALLOW CHILDREN TO USE A HAMMOCK WITHOUT ADULT SUPERVISION, AND DO NOT PLACE INFANTS IN A HAMMOCK.**

■ Do NOT drag or pull hammock stand when moving or adjusting it, even if using a wheel kit (purchased separately). **ALWAYS** lift stand from both ends, unless wheel kit is installed.

■ If a wheel kit is installed, lift and move stand at opposite end from the wheels.

■ **ALWAYS inspect hammock stand after moving or adjusting it, to make sure spring pins are still properly inserted.** Failure to do so may result in hammock stand collapsing during use.

■ Do NOT replace Offset S-Hooks with other hardware; the hooks that come with the stand are specially designed for it, to prevent exterior damage. For replacement hooks, contact The HammockSource toll-free, (800) 643-3522.